


REMOTE HANDSET CODING INSTRUCTIONS AVANTI TX4

TO CODE YOUR NEW REMOTE THE MOTOR PANEL

If you have access to the motor operating your door, you can use these instructions. However, if the door/gate motor is shared with other tenants at a residential/commercial complex, **do not** use these instructions.

To code in a new remote to a motor:

1. If needed hinge open the Courtesy Lamp Cover to expose the LEARN or CODE SET button otherwise it is on the rear of the motor head
2. Decide which button of the new remote will control the opener
3. Momentarily press the LEARN or CODE SET button – LED indicator will glow solid
4. Momentarily press the New Remote button you want to control the door – the LED indicator will extinguish
5. Momentarily press the same Remote button again – LED indicator will begin to flash quickly. Programming is complete once the LED indicator ceases to flash
6. If required close the Courtesy Lamp Cover



TO DELETE ALL STORED CODES FROM A DOOR

Do not do this if the door is shared with other tenants at a residential/commercial complex.

1. If needed hinge open the Courtesy Lamp Cover to expose the LEARN or CODE SET button otherwise it is on the rear of the motor head
2. Momentarily press the LEARN or CODE SET button – LED indicator will glow solid
3. Press and hold the black RUN button – LED indicator will begin to flash quickly
4. All Remote codes will have now been deleted once the LED indicator stops flashing
5. If required close the Courtesy Lamp Cover



Thank you for your purchase.

Our Customer Support team are available weekdays 8am-5pm on (07) 5476 9227 if you have any further questions.